



BYRNE

INSTALLATION INSTRUCTIONS FOR RIALTO

Lay Rialto on floor or large flat surface.



For Data, lay data cables in open Data Channels.



To disconnect Rialto unit:
**UNPLUG RIALTO STARTER FROM
ELECTRICAL OUTLET ON WALL.**