

# ENGLISH

**WARNING:** TO AVOID FIRE, SHOCK, OR DEATH, TURN OFF POWER AT CIRCUITBREAKER OR FUSE AND TEST THAT THE POWER IS OFF BEFORE WIRING!

**CAUTION:** Use this device only with copper or copper clad wire. With aluminum wire use only devices marked CO/ALR or CU/AL.

**TO INSTALL:**

**CAUTION:** When installing these devices, a Neutral wire is required for the outlet portion. When only one Black and one White wire are present in the wall box, the White wire is not necessarily a Neutral wire. If you are unsure or unable to determine the polarity of the two wires, consult a qualified electrician.

*Do not use to replace a switch that had been controlling a light with only two wires present.*

**CAUTION:** Break-off fin should be removed only when installing for separate feed (2 circuit) operation. Remove approx. 5/8" insulation from wire. Connect wires per appropriate diagram as follows: Loop wires clockwise 3/4 turn around terminal screws. Firmly tighten screws over wire loops. Terminal screws accept up to #12 AWG copper or copper clad wire. Attach wallplate and restore power. **Installation is complete.**

